

Switch Adapted Water Gun ASSEMBLY GUIDE

Required Components.

1



8



BOM

1. Electric Water Gun
2. Water Container
3. Water Gun Stand
4. A Button
5. Velcro
6. Screws
7. Screw Driver
8. Mono Jack Cable

2



4



5



7



3



6



Required Tools

- Screwdriver

Switch Adapted Water Gun

ASSEMBLY GUIDE

Required Personal Protective Equipment (PPE)

- Safety Glasses

Sources For Images (Due to not having the water gun available at the moment)

- The Elastic Cloth Tie Straps image is from amazon.com
- The Mono Jack Cable is from walmart.com

Assembly Instructions

Step 1

Remove 10 screws from the side of the water gun as pictured.




Switch Adapted Water Gun

ASSEMBLY GUIDE

Step 2


Remove and set aside the half of the water gun that was held down by the screws. In this step, you should have the ten screws set aside.



Step 3

Remove any other screws that are holding down the battery. Once removed, begin rewiring and soldering them to the two legs of the input jack that you install at the back of the water gun. Then, solder the other ends of the wires to the two mono jack legs near the nut of the jack. This setup will be later placed in between the batteries of the device to allow for the assistive switch in this case the button to be used instead of the trigger on the gun. This allows the wiring to connect to an external button input that would help control the trigger mechanism inside of the gun.

Switch Adapted Water Gun ASSEMBLY GUIDE



Step 4

Begin to reassemble the water gun by placing all parts back together and begin screwing the 10 screws into their designated areas.




Switch Adapted Water Gun

ASSEMBLY GUIDE

Step 5

Begin designing the two buttons you intend to connect to your water gun through tinkercad. These two buttons will be the assistive switch that we will use for our water gun. Once you have created your final designs on tinkercad, begin 3D printing your buttons.



Step 6

Once you have created two successfully designed buttons, begin to solder the button trigger and attach this trigger to a cable. This cable will be used to fire the water gun when clicked.

Switch Adapted Water Gun

ASSEMBLY GUIDE



Step 7

Connect the cable from the water gun to the external button and activate the water gun using the button. If the water gun does not shoot water, reattempt steps 1 through 6 and ensure that there is a clear connection between the trigger, the battery, the input port, and button.




Switch Adapted Water Gun

ASSEMBLY GUIDE

Step 8

Now that there is a clear connection between the assistive device and the water gun, begin designing your water gun support on tinkercad. To create a water gun support, measure the distance of the jaw of your water gun. Be sure to account for the width of the padding on the water gun support and ensure that it can hold the water gun in place. First, print only the part of the water gun support that holds the gun itself, not the entire foundation—to test the fit before completing a full 3D print.




Step 9

Once you have completed a 3D print of the water gun support, begin to create the arm strap that will be used to hold the water gun support in place on either a chair arm or an individual's arm. You can use a Velcro to keep the arm strap securely in place. Make sure that the length of the arm straps accounts for varying chair arms and varying individual arm lengths. Ensure that these arm straps can fit through the water gun support.

Switch Adapted Water Gun

ASSEMBLY GUIDE



Step 10

Place the gun on the water gun support and wrap the arm strap around the foundation and around your arm. Make sure that the water gun support rests comfortably on your arm. Once you have completed Step 10, you have created the water gun with a water gun support and two assistive switches.